WORKING

TIME TABLES

DOCUMENT NUMBER WPO - 04

ISSUE NUMBER 15.1

Amended December 2016

EFFECTIVE 10 DECEMBER 2016

UNCONTROLLED WHEN PRINTED

Authorised by Trevor Blight Operations Manager

TRAIN CONTROL 08 8391 2719







Controlled Document: This document is a controlled document and unless the authorisation signature is in blue ink is deemed to be an uncontrolled copy, the accuracy of which cannot be guaranteed. The copying of this document without the express approval of the Operations Manager is not permitted.

AMENDMENTS REGISTER

Page No.	Reference	Date of Issue	Amendment Detail	Authorised by
All	All	1 Oct 08	Issue 8 with revised schedules and typos	BoM
Various	Various	26 May 09	Removal of two per day CT servicees	BoM
Various	Scedules 9 & 10	10 Nov 19	Schedule 9 amend Strathlink to later return from Strathalubn and work 560 in liieu 562 Schedule 10 deleted as it is a repeat of schedule 9	BoM initla issue TN
Various	New Schedule	Nov 10	Southern Hills Special schedule ten added	ВОМ
14	Sched 9	Jan 12	Single working Slink & Cockle Train looc	Ops
9	Sch 5	Jan 13	Mid morning railcar ame4nded cross Middleton	BoM
13	Sch 9	Jan 13	Highlander depart Strathalbyn 15 minutes earlier	BoM
Various	Various	Feb 13	Amend SHS to reflect TN correction to times for SL add name SHS correct schedule 5	
9	Sch.5	April 2014	Revised schedule to provide for six trains a day.	BoM/Ops.
16 & 15	New Sch 11	March 2015	New Service – Finniss Flyer/Cockle Train Sch 11 Corrections to times Schedule TEN	Operations
Cover	T/C No.	24 Nov 2015	New Train Control No.	BOM/Ops
Various	Various	10 Dec. 2016	SCHEDULES 2, 5 & 11 Timetables changed: also Regulator, various instructions, correction of errors and typos, etc amendments on all pages.	Operations

INDEX

AMENDMENTS REGI	ISTER	1
INDEX		2
	TAILS	
DOCUMENT CONTR	ROL	3
TRAIN NUMBERING	G SYSTEM	4
TRAIN NAMES		4
BUGLE RANGER.		4
COCKLE TRAIN		4
HIGHLANDER		4
SOUTHERN ENCO	OUNTER	4
STRATHLINK		4
TWILIGHTER		4
SOUTHERN HILLS	S SPECIAL	۷
FINNISS FLYER		4
MOBILE PHONES		4
SCHEDULE ONE -	SOUTHERN ENCOUNTER & SUNDAY COCKLE TRAIN	5
SCHEDULE TWO -	HIGHLANDER & COCKLE TRAIN	<i>6</i>
SCHEDULE THREE -	REGULAR COCKLE TRAIN	
SCHEDULE FOUR –	COCKLE TRAIN WITH LATE AFTERNOON SERVICE	8
SCHEDULE FIVE -	COCKLE TRAINS - SIX TRAINS PER DAY	9
SCHEDULE SIX -	** SCHOOL HOLIDAY HIGHLANDER	10
SCHEDULE SEVEN -	BUGLE RANGER	11
SCHEDULE EIGHT -	**TWILIGHTER	
SCHEDULE NINE –	**COCKLE TRAIN & STRATHLINK	13
SCHEDULE TEN –	SOUTHERN HILLS SPECIAL	15
SCHEDULE ELEVEN -	- COCKLE TRAIN & FINNISS FLYER	16

^{**} Denotes - No service currently programmed.

TRAIN NOTICE DETAILS

This document sets out the schedules for trains operated by SteamRanger Tourist Railway on a regular basis. Schedule Numbers referred to in the Train Notice will be the Schedule Number shown on the top of the relevant page in this document.

Where movements, other than those detailed in this Working Time Table, are to operate a Train Notice will be authorised and issued.

DOCUMENT CONTROL

To conform with the requirements of the Rail Safety National Law (South Australia) Act 2012 and SteamRanger's Safety Management System Document No: ARHS-SMS-7 this document has been issued as a "controlled document" using the SteamRanger web site. Copies, once printed, are deemed "un-controlled" and it is the responsibility of each rail safety worker using this document to ensure that they have the latest version available for their use. SteamRanger workers who do not have access to electronic media will be issued with a hard copy of the document for which they will be required to sign for. SteamRanger shall advise rail safety workers who are required to use this document of changes as they are made.

Requests for any amendment to this document are to be forwarded in writing to the SteamRanger Operations Manager for consideration.

MT.BARKER AND MT.BARKER JUNCTION

The portion of railway between the turntable at Mt.Barker and Mt.Barker Jct is currently **CLOSED TO ALL TRAFFIC**

TRAIN NUMBERING SYSTEM

The following is a reprint from the Operations Procedure Victor Harbor Line - Document Number WP0 2 Section 2 paragraph 5.2

5.4.2 Train Numbering

All trains operating on the SteamRanger Heritage Railway shall be identified by a four digit number and the leading engine or railcar number.

The first digit of the number shall define the day of week on which the train is to operate with 1 being a Sunday and 7 Saturday. The second digit will define the station of origin for that train and where it is a return movement the final destination for the return movement on that day.. 1 = Mt.Barker, 2 = Strathalbyn, 5 = Goolwa Depot, 6 = Goolwa and 9 = Victor Harbor. The last two digits of the number relate to the service with even numbers being for movements towards Mt.Barker Junction (up trains) and odd numbers being for movements away from Mt.Barker Junction (down trains). Trains from Mt.Barker to Mt.Barker Junction shall be numbered in the range 00 - 09, Mt.Barker to Philcox Hill 10 - 29 range, Mt.Barker to Victor Harbor in the 30 - 39 range, Mt.Barker to Strathalbyn 40 - 49 range, Goolwa Depot - Victor Harbor in the 50 - 59 range. Other trains falling outside these locations shall be numbered in the 60 - 69 range. Transfer movements between Mt.Barker and Goolwa these movements shall be numbered in the range 70 – 79 range.

TRAIN NAMES

The following names apply to trains operated by SteamRanger and have reference to various schedules in this Working Timetable and the normal motive power used on these trains although this may vary from time to time -:

BUGLE RANGER Mt. Barker to Bugle Ranges operated by 400 class railcar

COCKLE TRAIN: Goolwa to Victor Harbor. Trains can be operated by head end power,

400/300 class railcar or Brill class railcar. Railcar trains may also include a trailer car. During the peak holiday periods the Cockle train is usually head end powered and predominantly steam hauled. Sunday and weekday Cockle trains operated independent of the Southern Encounter can be head end

power, 400/300 class railcar with trailer 824 or Brill class with trailer...

HIGHLANDER: Mt. Barker to Strathalbyn usually head end powered – generally by Steam..

SOUTHERN ENCOUNTER: Mt. Barker to Victor Harbor usually head end powered and

predominantly steam hauled from 1 June to 30 November. This usually includes a Cockle Train service from Victor Harbor to Goolwa and return as

part of the running.

STRATHLINK Goolwa to Strathalbyn then return to Victor Harbor – railcar service connects

with Cockle Train at Goolwa before running to Strathalbyn

TWILIGHTER Mt. Barker to Strathalbyn with an evening meal – usually head end powered.

SOUTHERN HILLS SPECIAL Railcar Victor Harbor to Mt. Barker – usually a Brill Railcar.

FINNISS FLYER Goolwa to Finniss by 400 class Railcar.

MOBILE PHONES

Details of mobile phones carried on each train are to be advised to the Train Controller by the Guard prior to departure from the originating station.

SCHEDULE ONE - SOUTHERN ENCOUNTER & SUNDAY COCKLE TRAIN Dates as detailed in annual programme

Train Number		<u>1551</u>	1131		<u>1951</u>
Mt.Barker	dep		1000		
Strathalbyn	arr		1050		
•	dep		1052		
Finniss	pass		1115		
Currency Creek	pass		1130		
Goolwa Depot	pass		1140		
_	dep	0945			1430
Goolwa	arr	0950	1145	1552	1435
	dep	1000	1215		1445
Middleton**	pass	1014	1229		1459
Port Elliot	arr	1019	1234		1504
	dep	1020	1235		1505
Victor Harbor	arr	1030	1245	turn	1515 turn
Work Train No.		1552	1950		1132
Work Train 10.		1332	1750		1132
Train Number		<u>1552</u>	1750	<u>1950</u>	<u>1132</u>
	dep		1730	<u>1950</u> 1330	<u> </u>
Train Number	dep arr	<u>1552</u>	1730		<u>1132</u>
Train Number Victor Harbor Port Elliot	_	<u>1552</u> 1100	1730	1330	
Train Number Victor Harbor	arr	1552 1100 1110	1730	1330 1340	
Train Number Victor Harbor Port Elliot	arr dep	1552 1100 1110 1111		1330 1340 1341 1346	
Train Number Victor Harbor Port Elliot Middleton**	arr dep pass	1552 1100 1110 1111 1116 1130 1131de 1155 LL*		1330 1340 1341 1346 s 1400 1405	
Train Number Victor Harbor Port Elliot Middleton**	arr dep pass arr	1552 1100 1110 1111 1116 1130 1131de		1330 1340 1341 1346 s 1400	
Train Number Victor Harbor Port Elliot Middleton** Goolwa Goolwa Depot	arr dep pass arr dep	1552 1100 1110 1111 1116 1130 1131de 1155 LL*		1330 1340 1341 1346 s 1400 1405	
Train Number Victor Harbor Port Elliot Middleton** Goolwa Goolwa Depot Currency Creek	arr dep pass arr dep arr	1552 1100 1110 1111 1116 1130 1131de 1155 LL*		1330 1340 1341 1346 s 1400 1405 1410	
Train Number Victor Harbor Port Elliot Middleton** Goolwa Goolwa Depot Currency Creek Finniss	arr dep pass arr dep arr pass	1552 1100 1110 1111 1116 1130 1131de 1155 LL*		1330 1340 1341 1346 s 1400 1405 1410	1132 1545 1555 1556 1601 1615 1617 1622 detach passenger car 1624 1635 1650
Train Number Victor Harbor Port Elliot Middleton** Goolwa Goolwa Depot Currency Creek	arr dep pass arr dep arr pass pass pass parr	1552 1100 1110 1111 1116 1130 1131de 1155 LL*		1330 1340 1341 1346 s 1400 1405 1410	
Train Number Victor Harbor Port Elliot Middleton** Goolwa Goolwa Depot Currency Creek Finniss Strathalbyn	arr dep pass arr dep arr pass pass pass	1552 1100 1110 1111 1116 1130 1131de 1155 LL*		1330 1340 1341 1346 s 1400 1405 1410	1132 1545 1555 1556 1601 1615 1617 1622 detach passenger car 1624 1635 1650 1713 1715
Train Number Victor Harbor Port Elliot Middleton** Goolwa Goolwa Depot Currency Creek Finniss	arr dep pass arr dep arr pass pass pass parr	1552 1100 1110 1111 1116 1130 1131de 1155 LL*		1330 1340 1341 1346 s 1400 1405 1410	

^{**} Stop if required for passengers to join or alight

Train 1552 to arrive main line at Goolwa then shunt to crossing loop. Cars to be attached to 1131

When the above movements are worked by diesel loco trains 1950/1951 will work to and from Goolwa only

Station Hours of Attendance

Mt.Barker: Unattended for Train Working - Ticket Officer on duty 0900hrs to train departure

Goolwa: Station Master on Duty from 0845hrs to 1215hrs or as advised. Ticket Officer on duty 0900 to 1500.

Victor Harbor: Station Master from 0900hrs to 1615hrs.

NOTE: Train 1132 may depart Goolwa and Strathalbyn up to 5 minutes ahead of schedule.

Load and Power: To be advised.

^{*}When Train 1552 is worked by Railcar 60, a second qualified Safe Worker must accompany the Driver to the Goolwa Depot – e.g. Trainee Driver or Goolwa Station Master.

SCHEDULE TWO - HIGHLANDER & COCKLE TRAIN

Dates as detailed in annual programme

<u>Train Number</u>		<u>1551</u>	<u>1141</u>	1555	_	<u>1557</u>
Mt.Barker Strathalbyn Finniss	dep arr dep pass		1000 1050 w	ater turi	1	
Currency Creek	pass	0045		1200*		1420 \$
Goolwa Depot Goolwa	dep arr dep	0945 0950 1000		1200* 1205* 1215		1430 * 1435 * 1445
Middleton**	pass	1014		1229		1459
Port Elliot	arr dep	1019 1020		1234 1235		1504 1505
Victor Harbor	arr	1030		1245		1515
Work Train No.		1552	1142	1556		1558
<u>Train Number</u>		<u>1552</u>		<u>1556</u>	<u>1142</u>	<u>1558</u>
Victor Harbor	dep	1100		1330		1545
Port Elliot	arr dep	1110 1111		1340 1341		1555 1556
Middleton** Goolwa	pass arr dep	1116 1130 1135*		1346 1400 1405*		1601 1615 1620
Goolwa Depot	arr pass	1140**	:	1410 *	*	1625
Currency Creek Finniss Strathalbyn	pass pass dep				1330	
Mt.Barker	arr				1420	
Work Train No.		1555				

^{**} Stop if required for passengers to join or alight

Station Hours of Attendance

Mt.Barker: Unattended for Train Working - Ticket Officer on duty 0900hrs to train departure.

Goolwa: Unattended for Train Working - Ticket Officer on duty 0900hrs to 1500hrs

Victor Harbor: Station Master 0900hrs to 1600hrs

Power: To be advised. **Load:** To be advised.

^{*} If required to turn

SCHEDULE THREE - REGULAR COCKLE TRAIN

Dates as detailed in annual programme

Train Number		<u>551</u>	<u>555</u>	<u>557</u>
Goolwa Depot Goolwa	dep arr	0945 0950	1200 1205	1430 1435
Middleton**	dep pass	1000 1014	1215 1229	1445 1459
Port Elliot	arr dep	1019 1020	1234 1235	1504 1505
Victor Harbor	arr	1030	1245 turn *	1515 turn *
Work Train No.		552	556	558
<u>Train Number</u>		<u>552</u>	<u>556</u>	558
Victor Harbor	dep	1100	1330	1545
Port Elliot	arr	1110	1340	1555
	dep	1111	1341	1556
Middleton**	pass	1116	1346	1601
Goolwa	arr	1130	1400	1615
	dep	1135*	1405*	1620
Goolwa Depot	arr	1140**	1410 **	1625
Work Train No.	* +	555	557	Stable
	" turn	if required		

tum m required

Station Hours of Attendance

Goolwa: Unattended for train working Ticket Officer 0900hrs – 1500hrs.

Victor Harbor: Station Master 0900hrs to 1600hrs.

Power: To be advised. **Load:** To be advised.

Authorisation is given for the operation of the above trains on the "daily Train Authority" for each day's operation. In the event of a need to operate an extra movement or if a perway vehicle is required to be "on track" the "daily" Train Authority is to be cancelled and replaced with single journey Train Authority. A mobile phone will be carried on the above trains and will be available for contact to the Guard during train running.

The above trains will not operate if the forecast maximum temperature for Victor Harbor is 35 degrees or above. When a total fireban has been declared for the Mt. Lofty Ranges and the temperature for Victor Harbor is predicted to be less than 35 degrees, trains will operate with diesel power.

^{**} Stop if required for passengers to join or alight

SCHEDULE FOUR - COCKLE TRAIN WITH LATE AFTERNOON SERVICE

Dates as detailed in annual programme

Train Number		<u>551</u>	<u>555</u>	<u>557</u>	<u>559</u>
Goolwa Depot	dep	0945	1200	1430	1600
Goolwa	arr	0950	1205	1435	1605 558
	dep	1000	1215	1445	1630
Middleton**	pass	1014	1229	1459	1644
Port Elliot	arr	1019	1234	1504	1649
	dep	1020	1235	1505	1650
Victor Harbor	arr	1030	1245 turn	1515 turn	1700 turn
`		*	*	*	
Work Train No.		552	556	558	560
					·
Train Number		552	<u>556</u>	<u>558</u>	<u>560</u>
Train rumoer					
Victor Harbor	dep	1100	1330	1545	1730
	dep arr		1330 1340	1545 1555	1730 1740
Victor Harbor	•	1100			
Victor Harbor	arr	1100 1110	1340	1555	1740
Victor Harbor Port Elliot	arr dep	1100 1110 1111	1340 1341	1555 1556	1740 1741
Victor Harbor Port Elliot Middleton**	arr dep pass	1100 1110 1111 1116	1340 1341 1346	1555 1556 1601	1740 1741 1746
Victor Harbor Port Elliot Middleton**	arr dep pass arr	1100 1110 1111 1116 1130	1340 1341 1346 1400	1555 1556 1601 1615 559	1740 1741 1746 1800
Victor Harbor Port Elliot Middleton** Goolwa	arr dep pass arr dep	1100 1110 1111 1116 1130 1135*	1340 1341 1346 1400 1405*	1555 1556 1601 1615 559 1620	1740 1741 1746 1800 1802
Victor Harbor Port Elliot Middleton** Goolwa	arr dep pass arr dep	1100 1110 1111 1116 1130 1135* 1140**	1340 1341 1346 1400 1405* 1410 **	1555 1556 1601 1615 559 1620	1740 1741 1746 1800 1802

^{*} water and turn as required

Station Hours of Attendance

Goolwa: Ticket Officer 0900hrs – 1700hrs unless advised that it is attended by a Station Master. Victor Harbor: Station Master 0900hrs to 1800hrs.

Load and Power: To be advised. Train 559/560 worked by railcar -400/300 class or Brill.

A mobile phone will be carried on the above trains and will be available for contact to the Guard during train running.

The above trains will not operate if the forecast maximum temperature for Victor Harbor is 35 degrees or above. When a total fireban has been declared for the Mt. Lofty Ranges and the temperature for Victor Harbor is predicted to be less than 35 degrees, trains will operate with diesel power.

If available, a Guard is to be rostered to work Train 559. Should a Guard not be available, the Driver of Train 559 between Goolwa Depot and Goolwa is to be assisted by a person qualified to STOP the train in the event of Driver incapacitation. Due to unavailability, the Guard of Train 558 is to work Train 559 from Goolwa whilst Train 558 continues from Goolwa to Goolwa Depot as a two person crew. The fireman of train 558 is to report to Train Control when the train has shunted clear of the main line at Goolwa Depot.

^{**} Stop if required for passengers to join or alight.

SCHEDULE FIVE - COCKLE TRAIN - (SIX TRAINS PER DAY)

Dates as detailed in annual programme

Train Number		* <u>551</u>	<u>*553</u>	<u>*555</u>	<u>*561</u>	<u>*557</u>	<u>*559</u>
Goolwa Depot	dep	0935	1035	1200	1305	1430	1600
Goolwa	arr	0940	1040	1205	1310	1435	1605 - 558
	dep	1000	1055	1215	1325	1445	1630
Middleton##	arr		1106*552	1229*554	1340*556	1459*562	
	##pass	1014					1644
	dep		1118	1230	1348	1500	
Port Elliot	arr	1018	1123	1234	1353	1504	1649
	dep	1020	1124	1235	1354	1505	1650
Victor Harbor	arr	1030	1135	1245	1405	1515	1700
`		+	+	+	+	+	+
Work Train No.		*552	*554	*556	*562	*558	*560
						·	
Train Number		* <u>552</u>	* <u>554</u>	* <u>556</u>	* <u>562</u>	<u>*558</u>	* <u>560</u>
Victor Harbor	dep	1100	1205	1330	1435	1545	1730
Port Elliot	arr	1110	1215	1340	1445	1555	1740
	dep	1112	1216	1342	1446	1556	1741
Middleton##	arr	1116*553	1221*555	1346*561	1451*557		
	##pass					1601	1746
	dep	1117	1231	1347	1501		
Goolwa	arr	1130	1245	1400	1515	1615559	1800
	dep	1132	1247	1402	1517	1620	1802
Goolwa Depot	arr	1136	1252	1406	1522	1625	1807
1		+	+	+	+		
Work Train No		*555	*561	*557	*559	Stable	Stable

⁺ Water and turn as required. Times between Goolwa and Goolwa Depot are only for movements required to turn.

Station Hours of Attendance

Goolwa - Ticket Officer: 0900hrs – 1700hrs unless advised that it is attended by a Station Master.

Middleton: Unattended for Train Working – Railcars are to take the Crossing Loop for all crosses. When two Loco hauled trains are scheduled, Locos 520, 621 and 958 must use the Main Line.

Victor Harbor - Station Master: 0900hrs to 1800hrs.

Load and Power: To be advised. **Trains 553/554/561/562/559/560**: To be advised.

A mobile phone will be carried on the above trains and will be available for contact to the Guard during train running.

The above trains will not operate if the forecast maximum temperature for Victor Harbor is 35 degrees or above. When a total fireban has been declared for the Mt. Lofty Ranges and the temperature for Victor Harbor is predicted to be less than 35 degrees, trains will operate with diesel power.

.

^{##} Stop if required for passengers to join or alight.

SCHEDULE SIX - SCHOOL HOLIDAY HIGHLANDER

Dates as detailed in annual programme

<u>Train Number</u> <u>141</u>

Mt.Barker dep 1030 Strathalbyn arr 1120

water turn

Work Train No. 142

Train Number 142

Strathalbyn dep 1400 Mt.Barker arr 1500

Work Train No. Stable

Station Hours of Attendance

Mt.Barker: Unattended for Train Working - Ticket Officer on duty 0930hrs to train departure..

Power: To be advised. **Load:** To be advised.

Phone: Guard to advise on the day.

SCHEDULE SEVEN - MT.BARKER - BUGLE RANGES

Dates as detailed in annual programme

<u>Train Number</u> <u>103</u>

Mt.Baker dep 1400 Bugle Ranges arr 1425

Work Train Number 104

Train Number 104

Bugle Ranges dep 1435 Mt.Barker arr 1500*

Work Train Stable (see footnote*)

Power: 400 class railcar

Station Hours of Attendance

Mt.Barker: Unattended for Train Working - Ticket Officer on duty 1300hrs to 1400hrs or later as required.

^{*} Additional trains may operate as required as train number x105 return x106 Mt.Barker and Bugle Ranges as advised by the Guard on the day.

SCHEDULE EIGHT-TWILIGHTER

Dates as detailed in annual programme

Train Number		<u>7145</u>
Mt.Barker Strathalbyn	dep arr	1830 1915
Work Train No.		7146
		·
Train Number		<u>7146</u>
Train Number Strathalbyn Mt.Barker	dep arr	7146 2200 2245

Station Hours of Attendance

Mt.Barker: Unattended for Train Working - ticket officer on duty 1745hrs to train departure.

Power: To be advised.

Phone: Guard to advise on the day.

SCHEDULE NINE – COCKLETRAIN & STRATHLINK

Dates as detailed in annual programme

Train Number		<u>551</u>	<u>553</u>	<u>555</u>		<u>557</u>		<u>559</u>
Strathalbyn Finniss Currency Ck Goolwa Depot	dep pass pass pass							1500 1525 1537 1545
Goolwa	dep arr dep	0945 0950 1000	1115 1125	1200 1205 1215		1430 1435 1445		1550 558 1630
Middleton** Port Elliot	pass arr dep	1014 1019 1020		1229 1234 1235		1459 1504 1505		1644 1649 1650
Victor Harbor	arr	1030		1245	turn	1515	turn	1700
Work Train No).	552	554	556		558		560
Train Number		<u>552</u>		<u>554</u>	<u>556</u>		558	<u>560</u>
Victor Harbor Port Elliot	dep arr dep	1100 1110 1111			1330 1340 1341		1545 1555 1556	1730 1740 1741
Middleton** Goolwa	pass arr dep	1116 1130 1145	wait cl	earance	1346 1400 1405*		1601 1615 - 559 1620	1746 1800 1802
Goolwa Depot	arr dep	1150		 1140 re	1410 *	*	1625	1807
Currency Ck Finniss Strathalbyn	pass pass arr			1151 1206 1226				
Work Train No) .			559 * turn	555	557	Stable	Stable

^{**} Stop if required for passengers to join or alight.

Station Hours of Attendance

Goolwa: Station Master 0900hrs to 1645hrs. Victor Harbor: Station Master 0900hrs to 1745hrs,

Load and Power: To be advised. Trains 553/554/559/560 to be worked by BRILL Railcar.

A mobile phone will be carried on the above trains and will be available for contact to the Guard during train running.

The above trains will not operate if the forecast maximum temperature for Victor Harbor is 35 degrees or above. When a total fireban has been declared for the Mt. Lofty Ranges and the temperature for Victor Harbor is predicted to be less than 35 degrees, trains will operate with diesel power. Train 551, when worked by F 251, will normally proceed to ash pit at Victor Harbor to clean the ash pan.

Train 553 will work in reverse gear Goolwa Depot to Goolwa and stand on the Adelaide end of the passenger platform to allow passengers to transfer from train 552 and then work train 554 to Strathalbyn.

Train 559 will on arrival at Goolwa take the main line to allow any Goolwa passengers to alight. Train to then shunt to crossing loop via Goolwa Depot end of the yard and after the arrival of train *558 to shunt back to the main line to collect any passengers returning to Victor Harbor from train *558.

SCHEDULE TEN – SOUTHERN HILLS SPECIAL (VICTOR HARBOR TO MT.BARKER)

Dates as detailed in annual programme

Train Number		* <u>551</u>	<u>*931</u>
Mt.Barker	dep		1500
Strathalbyn	arr		1550 toilet stop
·	dep		1605
Finniss	pass		1625
Currency Creek	pass		1638
Goolwa Depot	pass		1648
•	dep	0900 Empty	
Goolwa	arr		1653
	dep	0905	1655
Middleton	pass	0919	1709
Port Elliot	arr		1714
	dep	0923	1715
Victor Harbor	arr	0933 turn	1725
Work Train No.		*930	*552
Tuoin Namahan		*930	*550
<u>Train Number</u>		*930	* <u>552</u>
Victor Harbor	dep	1000	1745 Empty – may depart from Turntable
Port Elliot	arr	1010	
	dep	1011	1757
Middleton	pass	1016	1802
Goolwa	arr	1030	
	dep	1032	1816
Goolwa Depot	arr		1821
1	pass	1037	
Currency Creek	pass		
Currency Creek Finniss	pass pass	1045	1
Finniss	pass pass arr	1045 1055	
•	pass arr	1045	
Finniss	pass arr dep	1045 1055 1115 Toilet sto	
Finniss Strathalbyn	pass arr	1045 1055 1115 Toilet sto 1130	

Train *551 to take the Turntable road on arrival at Victor Harbor then push back to pick up passengers.

Station Hours of Attendance

Mt.Barker: Unattended Goolwa: Unattended

Victor Harbor: Station Master 0900hrs to 1030hrs then 1615hrs to 1745hrs.

Power:- Car 60

Note: Seats for these trains should be pre booked

SCHEDULE ELEVEN – COCKLE TRAIN & FINNISS FLYER Dates as detailed in annual programme

Train Number		<u>*551</u>	<u>*553</u>	<u>*555</u>	<u>*561</u>	<u>*557</u>	<u>*563</u>
Finniss	dep				1235		1410
Currency Creek	pass				1250		1424
Goolwa Depot	arr dep pass	0930	1100	1205LL	1300	1425LL	1434T/A 1435
Goolwa	arr dep	0935 1000	1105	1210 1215	1305	1430 1445&&	1440
Middleton##	pass	1014		1229		1459	
Port Elliot	arr dep	1019 1020		1234 1235		1504 1505	
Victor Harbor	arr	1030		1245		1515	
Work Train No.		*552	*554	*556	*562	*558	*564
Train Number		<u>*552</u>	<u>*554</u>	<u>*562</u>	<u>*556</u>	<u>*564</u>	<u>*558</u>
Victor Harbor	dep	1100			1330		1545
Port Elliot	arr dep	1110 1111			1340 1341		1555 1556
Middleton##	pass	1116			1346		1601
Goolwa	arr dep	1130 1145LL	1135%%	1310	1400 1405LL	1455	1615 1620
Goolwa Depot	arr	1150^^			1410^^		1625
	dep pass		1140Rpt.	1315		1500	
Currency Creek	pass		1150	1325			
Finniss	arr		1205	1340			
Work Train No.		*555	*561	*563	*557	Stable	Stable

^{^^} Turn, and Water if required.

%% *554 waits - Connects with *552.

&& *557 Waits - Connects with *563.

Stops at Middleton, if required, for passengers to join or alight.

Station Hours of Attendance

Goolwa - Station Master 0900hrs to 1645hrs.

Victor Harbor – Station Master 0900hrs to 1600hrs.

Load and Power: Cockle Trains - to be advised.

Trains *553, *554, *561, *562, *563, *564 – Redhen Railcar.

A mobile telephone will be carried on the above trains and will be available for contact to the Guard during train running.

The above trains will not operate if the forecast maximum temperature for Victor Harbor is 35 degrees or above. When a total fire ban has been declared for the Mt. Lofty Ranges and the temperature for Victor Harbor is predicted to be less than 35 degrees, trains will operate with Diesel power.

Train *553 will work from Goolwa Depot to Goolwa and stand at the Adelaide end of the passenger platform to allow passengers to transfer from Train *552 and then work Train *554 to Finniss. The loco ex Train *552 is to follow after Train *554 has cleared Goolwa Depot.

Train *556 is to stop at the Goolwa platform allowing sufficient room at the Mt. Barker end of the platform for Train *563 to be admitted behind Train *557 thus enabling passengers for both Goolwa and the connecting Train *557 to Victor Harbor to alight.